

EXHIBIT G-2

THIS REPORT PREPARED PURSUANT TO DUTY IMPOSED BY A.A.C. R-13-10-104 (A)

ARIZONA DEPARTMENT OF PUBLIC SAFETY  
STANDARD QUALITY ASSURANCE PROCEDURES  
INTOXILYZER MODEL 8000  
STANDARD CALIBRATION CHECK PROCEDURE

QA SPECIALIST DEPUTY JOHN M. GOMEZ #220 AGENCY LA PAZ COUNTY SHERIFF'S OFFICE

DATE 08 / 22 / 2015 TIME 16:24 Hrs

INTOXILYZER SERIAL # 80 - 001196 LOCATION BACK UP / EHRENBERG SUBSTATION

(✓) 1. Ensure that gas tank is attached to instrument and contains a standard alcohol concentration solution 0.100 AC.

OR

Pour a standard alcohol concentration solution \_\_\_\_\_ AC, into a clean dry simulator and assemble the simulator. Ensure that a tight seal has been made. Turn on the simulator and allow temperature to reach 34 C 0.2 C

(✓) 2. Intoxilyzer 8000 display reads "PUSH BUTTON TO START"

(✓) 3. Go to the "Control Testing Menu". Select "D" for dry control test or "W" for wet control test. After selection is made press ENTER.

(✓) 4. Air blank completed.

(✓) 5. Calibration check completed. Test results 0. 095 AC.

(✓) 6. Air blank completed.

(✓) 7. Remove printed record. Attach the record to the completed checklist.

SIGNATURE \_\_\_\_\_

INTOXILYZER 8000

Location: EHRENBERG SUBSTATION

Serial Number: 80-001196

Core Version: 8105.48

08/20/2015

16:24:13

-----  
Standard Lot#: 08915100A2

Last Changed By: E. SCHNEIDER #431

-----  
QAS: J. GOMEZ #220

LA PAZ CSO

-----  
Operator: J. GOMEZ #220

LA PAZ CSO

-----  
Test                      g/210L                      Time  
-----  
Air Blank                      0.000                      16:24:45  
0.100 Cal Check                0.095                      16:25:06  
Air Blank                      0.000                      16:25:35

Preventative Maintenance  
Performed -- Timer Reset

A handwritten signature in black ink, appearing to be 'J. Gomez', with the number '220' written below it.