

EXHIBIT G-2
THIS REPORT PREPARED PURSUANT TO DUTY IMPOSED BY A.A.C. R13-10-104 (A)

ARIZONA DEPARTMENT OF PUBLIC SAFETY
STANDARD QUALITY ASSURANCE PROCEDURES
INTOXILYZER MODEL 8000
STANDARD CALIBRATION CHECK PROCEDURE

QA SPECIALIST R. EPAS AGENCY LAPAZ S.O.
DATE 10/2/12 TIME 1552
INTOXILYZER SERIAL # 80-000934 LOCATION LAPAZ JAIC

- WAS* 1. Ensure that gas tank is attached to instrument and contains a standard alcohol concentration solution 100 AC.
OR
Pour a standard alcohol concentration solution — AC, into a clean dry simulator and assemble the simulator. Ensure that a tight seal has been made. Turn on the simulator and allow temperature to reach $34^{\circ}\text{C} \pm 0.2^{\circ}\text{C}$
- WAS* 2. Intoxilyzer 8000 display reads "PUSH BUTTON TO START"
- WAS* 3. Go to the "Control Testing Menu". Select "D" for dry control test or "W" for wet control test. After selection is made press ENTER.
- WAS* 4. Air blank completed.
- WAS* 5. Calibration check completed. Test results 0. 096 AC.
- WAS* 6. Air blank completed.
- WAS* 7. Remove printed record. Attach the record to the completed checklist.

SIGNATURE SGT. M. GY

INTOXILYZER 8000

Location: LPCSO JAIL

Serial Number: 80-000934

Core Version: 8105.48

11/02/2012

15:52:04

Standard Lot#: 15712100A1

Last Changed By: R. EPPS #90

QAS: R. EPPS #90

LA PAZ CSO

Operator: R. EPPS #90

LA PAZ CSO

Test g/210L Time

Air Blank 0.000 15:52:36
0.100 Cal Check 0.096 15:52:56
Air Blank 0.000 15:53:26

Preventative Maintenance
Performed -- Timer Reset